

AMERICA COMFORT CUSHION .COM


DIRECTIONS



STRAP WRAPS UNDER THE ARM CLIPPING IN THE FRONT OF THE BODY.

THE STRAP THAT IS ON THE SIDE OF THE NECK CUTOUT WRAPS ACROSS THE CHEST.

WRAP THE CHEST STRAP UNDER THE LEFT ARM, CLIPPING IT INTO PLACE AT THE FRONT OF THE CHEST.



WRAP STRAP FROM THE BACK, CLIPPING IT AT THE FRONT OF THE ARM.

BACKSIDE DIAGRAM

FRONTSIDE DIAGRAM

PAD INSERTION

TO CHANGE PADS FOLD THE PAD IN HALF AND SLIDE INTO POCKET.

ONCE PAD IS INSIDE ZIPPER POCKET, UNFOLD PAD UNTIL IT LIES FLAT.

EACH PAD IS CUT TO FIT THE POCKET SNUGLY.

RETURN POLICY

ALL PADS CAN BE RETURNED AND REPLACED IF THERE IS A MANUFACTURER DEFECT WITHIN 30 DAYS OF PURCHASE.

ALL PADS ARE MACHINE WASHABLE IN COLD WATER. REMOVE PADS BEFORE WASHING OUTER NEOPRENE SHELL.